



PS00004945 A01

## GL20-4AD Analog Input Module User Guide

Shenzhen Inovance Technology Co., Ltd.

Add.: Inovance Headquarters Tower, High-tech Industrial Park,

Guanlan Street, Longhua New District, Shenzhen

Tel: (0755) 2979 9595

Fax: (0755) 2961 9897

[www.inovance.com](http://www.inovance.com)





# Preface

## ■ About This Guide

GL20-4AD series 4-channel analog input module supports voltage and current input with a 16-bit resolution, and can be used together with a PLC master such as Easy series.

This guide describes the mechanical installation, electrical installation and programming examples of the product.

## ■ More Data

Data Name	Data Code	Description
GL20-RTU-ECT Communication Interface Module User Guide	PS00004985	This guide describes the installation, wiring and more of the product.

## ■ Revision History

Date	Version	Description
June 2022	A01	Minor corrections
March 2022	A00	First release.

## ■ How to Obtain

This guide is not delivered with the product. You can obtain the PDF version by the following method:

- Log in to Inovance's website (<http://en.inovance.cn/>), choose **Support** > **Download**, search by keyword, and then download the PDF file.
- Scan the QR code on the product with your mobile phone.

## ■ Warranty Agreement

The warranty period of the product is 18 months as of the date of manufacture (refer to the barcode on the equipment). If otherwise agreed upon, the agreed terms and conditions shall prevail. After 18 months, a proper maintenance fee is charged.

Within the 18-month warranty period, a reasonable repair fee will be charged for damages caused by the following:

- Operations not following the user instructions
- Fire, flood, or abnormal voltage

- Use of the product for non-recommended functions
- Use of the product outside the scope of intended use
- Force majeure such as natural disasters, earthquake, lightning strike

The maintenance fee is charged according to the latest Price List of Inovance. If otherwise agreed upon, the agreed terms and conditions shall prevail.

For details, see Product Warranty Card.

# Safety Instructions

## ■ Safety Precautions

1. Read and comply with the safety instructions during installation, operation, and maintenance on the equipment.
2. To ensure the safety of humans and the products, follow the marks on the products and all the safety instructions in this document.
3. The "CAUTION," "WARNING," and "DANGER" signs are only supplements to the safety instructions.
4. Use this equipment according to the designated environment requirements.  
Damage caused by improper use is not covered by warranty.
5. Inovance shall take no responsibility for any personal injuries or property damage caused by improper use.

## ■ Safety Levels and Definitions



**Danger:** Indicates that failure to comply with the notice will result in severe personal injuries or even death.



**Warning:** Indicates that failure to comply with the notice may result in severe personal injuries or even death.



**Caution:** Indicates that failure to comply with the notice may result in minor or moderate personal injuries or damage to the equipment. Please keep this guide well so that it can be read when necessary and forward this guide to the end user.

### During Control System Design



**Danger**

- Provide a safety circuit outside the PLC so that the control system can still work safely once external power failure or PLC fault occurs.
- Add a fuse or circuit breaker because the module may smoke or catch fire due to long-time overcurrent caused by operation above rated current or load short-circuit.



#### Warning

- An emergency stop circuit, a protection circuit, a forward/reverse operation interlocked circuit, and a upper position limit and lower position limit interlocked circuit must be set in the external circuits of PLC to prevent damage to the machine.
- To ensure safe operation, for the output signals that may cause critical accidents, design external protection circuit and safety mechanism;
- Once PLC CPU detects abnormality in the system , all outputs may be closed; however, when a fault occurs in the controller circuit, the output may not be under control. Therefore, it is necessary to design an appropriate external control circuit to ensure normal operation;
- If the PLC output units such as relays or transistors are damaged, the output may fail to switch between ON and OFF states according to the commands;
- The PLC is designed to be used in indoor electrical environment (overvoltage category II). The power supply must have a system-level lightning protection device, assuring that overvoltage due to lightning shock cannot be applied to the PLC power supply input terminals, signal input terminals and output terminals and so forth, so as to avoid damage to the equipment.

## Installation



#### Warning

- Installation must be carried out by the specialists who have received the necessary electrical training and understood enough electrical knowledge.
- Disconnect all external power supplies of the system before removing/installing the module. Failure to do so may result in electric shock, module fault or malfunction.
- Do not use the PLC where there are dust, oil smoke, conductive dust, corrosive or combustible gases, or exposed to high temperature, condensation, wind & rain, or subject to vibration and impact. Electric shock, fire and malfunction may also result in damage or deterioration to the product.
- The PLC is open-type equipment that must be installed in a control cabinet with lock (cabinet housing protection > IP20). Only the personnel who have received the necessary electrical training and understood enough electrical knowledge can open the cabinet.



#### Caution

- Prevent metal filings and wire ends from dropping into ventilation holes of the PLC during installation. Failure to comply may result in fire, fault and malfunction.
- Ensure there are no foreign matters on ventilation surface. Failure to comply may result in poor ventilation, which may cause fire, fault and malfunction.
- Ensure the module is connected to the respective connector securely and hook the module firmly. Improper installation may result in malfunction, fault or fall-off.

### Wiring



#### Danger

- Wiring must be carried out by personnel who have received the necessary electrical training and understood enough electrical knowledge.
- Disconnect all external power supplies of the system before wiring. Failure to comply may result in electric shock, module fault or malfunction.
- Install the terminal cover attached to the product before power-on or operation after wiring is completed. Failure to comply may result in electric shock.
- Perform good insulation on terminals so that insulation distance between cables will not reduce after cables are connected to terminals. Failure to comply may result in electric shock or damage to the equipment.



#### Caution

- To avoid electric shock, cut off the power supply before connecting the product to the power supply.
- The input power of the product is 24 VDC. If the power input is not within  $24\text{ VDC} \pm 20\%$ , the product may be damaged. Therefore, check regularly that the DC power provided by the switching-mode power supply unit is stable.

### During Operation and Maintenance



#### Caution

- Maintenance & inspection must be carried out by personnel who have the necessary electrical training and experience.
- Do not touch the terminals while the power is on. Failure to comply may result in electric shock or malfunction.
- Disconnect all external power supplies of the system before cleaning the module or re-tightening screws on the terminal block or screws of the connector. Failure to comply may result in electric shock.
- Disconnect all external power supplies of the system before removing the module or connecting/removing the communication wirings. Failure to comply may result in electric shock or malfunction.

### Safety Recommendations

- On-site manual devices or other backup means must be equipped in the position where the operator directly touches the mechanical parts, such as loading and unloading mechanical tools, or the position where the machine runs automatically. The manual devices and backup means, which can start or interrupt automatic operations of the system, must be independent of the programmable controller.
- If you need to modify the program while the system is running, use the lock function or other protective measures. Ensure that only authorized personnel can make the necessary modifications.

### Disposal



#### Caution

- Treat the scrapped product as industrial waste. Dispose of the battery according to local laws and regulations.
- Recycle retired equipment by observing industry waste disposal standards to avoid environmental pollution.




# 1 产品信息

## 1.1 Model Number and Nameplate

GL  
①
20  
②
- 4  
③
AD  
④

<p>① <b>Product Information</b> GL: General local module</p>	<p>③ <b>I/O Points</b> 4: 4 channels 8: 8 channels</p>
<p>② <b>Serial Number</b> 20: 20 series module</p>	<p>④ <b>Module Type</b> AD: Analog input DA: Analog output AM: Hybrid module PT: Heating resistor temperature measurement TC: Thermocouple temperature detection</p>










Based on the above description of model number and nameplate, the relevant ordering data of this product is described in the following table.

Model	Description	Product Code	Applicable Model
GL20-4AD	GL20 series 4-channel analog input module supports voltage/current input.	01440288	AC800 series, Easy series

## 1.2 Components

The following describes the terminals of the module.



No.	Name	Description			
1	Signal indicators	PR (POWER +RUN)	Power / running indicator	Yellow green	ON when the module is in normal operation
		ERR	State machine error indicator	Red	ON when an error occurs in the state machine
2	Terminals	See Terminal Definition for detailed definition			
3	Color identification		Red: Digital output		Orange: Analog output
			Gray: Digital input		Green: Analog input
			White: Communication		Blue: Other module

## 1.3 Specifications

### ■ Power supply specifications

Item	Specification
Rated bus input voltage	5 VDC (4.75 VDC to 5.25 VDC)
Rated bus input current	120 mA (typical@5 V)
Rated terminal input voltage	5 VDC (20.4 VDC to 28.8 VDC)
Rated terminal input current	50 mA (typical@24 V)
Rated terminal output voltage	N/A
Rated terminal output current	N/A
Hot swap	Not supported

### ■ Input specifications

Item	Description
Input type	Analog input
Input mode	Voltage/Current
Input channels	4
Resolution	16-bit
Conversion time	60 us/ channel
Voltage input range	$\pm 10$ V, 0 to 10 V, $\pm 5$ V, 0 to 5 V, 1 to 5V
Voltage input impedance	1M $\Omega$
Voltage input accuracy (25°C)	$\pm 0.1\%$ (full range)
Voltage input accuracy (full temperature range)	$\pm 0.2\%$ (full range)
Voltage input limit	$\pm 15$ V
Voltage input diagnosis	Wire breakage detection not supported
Current input range	$\pm 20$ mA, 0 to 20 mA, 4 to 20 mA
Current sampling impedance	250 $\Omega$
Current input accuracy (25°C)	$\pm 0.1\%$ (full range)

Item	Description
Current input accuracy (full temperature range)	$\pm 0.2\%$ (full range)
Current input limit	$\pm 30$ mA (transient), $\pm 24$ mA (average)
Current input diagnosis	Wire break detection supported only when set to 4 to 20 mA
Isolation	No isolation between the channels; Isolation between the channels and the power supply; Isolation between the channels and the bus
Input action display	N/A
Input derating	N/A

## ■ Software specifications

Item	Description
Independent channel enable configuration	Supported
Diagnostic report configuration	Supported
Diagnostic detection configuration	Short circuit detection and wire break detection, not supported by output range containing 0
Conversion mode configuration	$\pm 10$ V, 0 to 10 V, $\pm 5$ V, 0 to 5 V, 1 to 5 V, $\pm 20$ mA, 0 to 20 mA, 4 to 20 mA
Filter parameter configuration	The software filtering time can be configured through the host controller, the setting range is 0-65535
Overlimit detection configuration	Supported
Peak hold configuration	Supported
Digital output range configuration	The default is consistent with that of GL10 (-20000 to 20000) and supports $\pm 32000$
Sampling time	250 us for four channels


Item	Description
Sampling refresh	Refresh asynchronously according to the sampling time, not required to refresh synchronously according to the bus cycle
When in stop mode	Output last value, no refresh

## 2 Mechanical Installation


### 2.1 Mounting Dimensions

#### ■ Module

The mounting dimensions (in mm) are shown in the figure below.




#### ■ Cable Connection



## 2.2 Installation Method

### ■ Installing Modules Side-by-Side

You can install multiple modules side by side with the help of top and bottom guides on the modules, as shown below.




### ■ Installing Module onto DIN Rail

You can install the module onto a DIN rail. Align the module with the DIN rail and push the module in the direction indicated by the arrow until you hear a click, as shown below.



**Note:** After the module is installed, the DIN rail mounting hook will automatically move downward to lock the module to the rail. If the hook does not move downward, press down the top of the hook to ensure that the module is installed in place.

Mount an end plate on either side of the module assembly. To mount the end plate, hook the bottom of it to the bottom of the DIN rail, rotate the end plate to hook the top of it to the top of the DIN rail, and then tighten the screw to lock the end plate in place, as shown below.



## ■ Removing Module

Pry the DIN rail mounting hook upwards with a tool such as slotted screwdriver, hold the protrusions and pull the module out straight forward, and then press down the top of the DIN rail mounting hook.






## 3 Electrical Installation

### 3.1 Cable Selection

The cable lug and cable diameter included in the following table are only for reference.

Material Name	Applicable Cable Diameter		KST		Suzhou Yuanli	
	mm <sup>2</sup>	AWG	Model	Crimping Tool	Model	Crimping Tool
Tubular lug	0.3	22	E0308	KST2000L	0308	YAC-5
	0.5	20	E0508		0508	
	0.75	18	E7508		7508	
	1.0	18	E1008		1008	
	1.5	16	E1508		1508	

If you use other types of tubular lug, crimp the lug to the cables according to the shape and dimension requirements shown in the figure below.



## 3.2 Terminal Definition



Signal	Left Terminal	Right Terminal	Signal
VI0+	A1	B1	VI1+
I0+	A2	B2	I1+
VI0-	A3	B3	VI1-
VI2+	A4	B4	VI3+
I2+	A5	B5	I3+
VI2-	A6	B6	VI3-
-	A7	B7	-
PE	A8	B8	PE
24 V	A9	B9	COM


## 3.3 Terminal Wiring

### ■ Wiring Precautions



- Do not bundle the extension cable together with power cables (high voltage, large current) which produce strong interference signals; otherwise, it may be influenced by noise, surge and induction. Separate it from other cables and avoid cabling in parallel.
- Select recommended cables and pinboards for connection. It is recommended that shielded cables be used as extension cables to enhance capacity of resisting interference.
- Apply single-point grounding for the shielding of shielded cable and solder sealed cable.

## External Wiring

(a) Voltage input



(b) Current input




- \*1 Use 2-core shielded twisted pair cable for analog signal.
- \*2 Indicates input impedance of 4AD.
- \*3 For current input, terminal (V+) must be connected to terminal (I+).


## 4 Programming Examples

The following is an example where the input voltage of channel 0 of the GL20-4AD module is assigned to the corresponding variable, and AC802 is used as the master control module.


### 1. Add GL20-4AD module.



### 2. In the **Channels Config** interface, check **Enable access** for Access-0, and set the parameters as per needs.



### 3. Define variables AD\_CH0, AD\_CH1, AD\_CH2 and AD\_CH3 with the ST programming language as shown in the figure below.



4. Map the defined variable AD\_CH0 to channel 0 of the configured GL20-4AD module.

The screenshot shows the TIA Portal interface with the 'Network Configuration' window open. The 'Find' tab is active, displaying a table of variables and their mappings.

Variable	Mapping	Channel	Address	Type	Unit	Description
Application.PLC_PRG.AD_CH0		Device control	%QW6	UINT		Device control
		LBUS status	%IW0	UINT		LBUS status
		Fault ID	%IW1	UINT		Fault ID
		GL20_4AD AD CH0	%IW2	INT		GL20_4AD AD CH0
		GL20_4AD AD CH1	%IW3	INT		GL20_4AD AD CH1
		GL20_4AD AD CH2	%IW4	INT		GL20_4AD AD CH2
		GL20_4AD AD CH3	%IW5	INT		GL20_4AD AD CH3

The 'Input Assistant' window is also open, showing the 'Variables' tab. The variable 'AD\_CH0' is selected, and its type is 'INT'.

The 'Input Assistant' window also shows a list of variables and their types:

Name	Type	Address	Origin
Application	Application		
PLC_PRG	PROGRAM		
AD_CH0	INT		
AD_CH1	INT		
AD_CH2	INT		
AD_CH3	INT		
IoConfig_Globals	VAR_GLOBAL		
IoDrvEthercatLib	Library		IODrvEtherCAT, 3.5...
SM3_Basic	Library		SM3_Basic, 4.10.1.0 ...
SM3_CNC	Library		SM3_CNC, 4.2.1.1 (3...
SM3_Math	Library		SM3_Math, 4.10.0.0 ...

5. After successful compiling, download the project and run it.